
Experiment A10 Transient Signals Procedure

Deliverables: Checked lab notebook, Brief technical memo

Overview

In this lab, you will investigate the dynamic response of measurement systems. A thermocouple serves as a great example of first-order transient response, and a baseball bat is used to demonstrate second-order system transient response. A handheld LabQuest unit will be used as an A/D for acquiring data from the thermocouple.

Part I: First-Order Transient Response

A thermocouple (TC) acts as a typical first-order dynamic system due to heat transfer properties of the TC. The inner workings of the TC consist of a pair of dissimilar wires connected via two junctions called a hot and cold junction. A difference in temperature between the junctions forms a voltage difference across them. This voltage is proportional to the temperature difference. Material and size of the metal probe will affect the heat distribution in the thermocouple rod and can either shorten or lengthen the time it takes to reach a steady-state temperature. The exchange of heat through the thermocouple can be described by:

$$mC_v \frac{dT}{dt} = hA_s [T_\infty - T(t)], \quad (1)$$

where m is the tip mass, C_v is the specific heat at a constant volume for the tip, A_s is the tip surface area, h is the heat transfer coefficient, and T_∞ is the far-field temperature of the surrounding fluid. The explicit solution to the differential equation is:

$$T(t) = T_\infty + (T_0 - T_\infty) \exp\left(\frac{-t}{\tau}\right). \quad (2)$$

where T_0 is the initial temperature and the time constant $\tau = \frac{mC_v}{hA_s}$. Mathematically, the time constant represents the time it takes the system to go from the initial temperature T_0 to $1 - \frac{1}{e} \approx 63.2\%$ of the steady-state temperature T_∞ .

Procedure

1. Ensure that the small (1/16") thermocouple (TC) is connected to the thermocouple amplifier box and then turn it ON. Connect the amplifier to Channel 1 on LabQuest using a BNC cable and the provided 5 volt cable. Be sure that the source and GND are connected properly. Record thermocouple amplifier sensitivity coefficient (labeled on the TC amplifier) in your lab notebook.
2. Turn the power on the LabQuest unit ON. In the "LabQuest App", click 'File' → 'New' to erase any previous data that may be on the device.
3. Go to 'Sensors', select 'Sensor Setup', and set Channel 1 to Voltage → Raw Voltage (0 – 5V).
4. Compare ambient temperature using mercury thermometer to reading on labquest. Write down both values in your lab notebook. Let TA know if there is a significant difference.
5. Edit the data acquisition options by selecting the region with *mode*, *rate*, and *length*. Choose an appropriate rate (35 samples/second) and set the duration to be long enough to see the steady-state behavior (about 10 seconds is a good starting duration).
6. Fill a beaker with warm water. Fill another beaker with ice water.
7. Let the TC sit in the warm water for a minute. Begin acquiring data by pressing the (▶) symbol on LabQuest. After a few seconds, remove it from the warm water and submerge the tip of the TC into the *ice water*. (Best results are obtained when the TC end is suspended.) Do not let the tip of the TC rod touch the bottom of the beaker. Allow LabQuest to take data for the entirety of the length specified.
8. Press the little file cabinet icon in the top right corner to store the data in memory.
9. Let the TC sit in the ice water for about a minute. Press the (▶) symbol on LabQuest. After a few seconds, remove the TC from the ice water and immediately submerge it in the *warm water*. Keep it submerged until data collection is complete.
10. Connect the LabQuest to the computer and transfer the data to the lab computer using the LoggerPro software. Export the data from LoggerPro as a CSV file. Be sure to give it a good, descriptive file name and email it to your lab partner.
11. Repeat the procedure using the large (1/4") thermocouple. Set the duration to 25 seconds.

Part II: Measuring Vibrations in a Baseball Bat

Background

A baseball bat is a familiar example of a mechanical, dynamic system. When the bat strikes the ball, the impact causes some elastic deformation of the bat, displacing it from equilibrium some distance y . Because the bat has mass and elasticity, we can model it as a harmonic oscillator. The batter's hands absorb energy from these vibrations, providing an effective damping force—an effect some of you may be familiar with. Hence, the baseball bat behaves very much like a *damped harmonic oscillator*, which we studied in the previous lab. However, the striking of the ball is an *impulse force*, because it happens ‘instantaneously’ as opposed to the sinusoidal driving force we saw last week.

When a damped harmonic oscillator is hit with an impulse, it will respond by “ringing”. This ringing behavior is described by the equation

$$y_{bat}(t) = Ae^{-\lambda t} \sin(\omega_d t + \phi), \quad (3)$$

where ω_d is the ringing frequency, λ is the damping coefficient scaled by mass, and A and ϕ are constants dependent on initial conditions. In this lab, you will use strain gauges to measure the scaled damping coefficient λ , the ringing frequency ω_d , and the phase ϕ of a vibrating aluminum baseball bat.

Setup and Data Acquisition

The bat for this laboratory exercise is outfitted with four strain gauges in a full bridge configuration, which respond to the displacement of the bat y_{bat} versus time t . Shown in Fig. 1, the strain gauges are connected to an amplifier to increase the output voltage, and the output voltage is recorded by an oscilloscope, which samples at a very high rate (GHz – which easily satisfies the Nyquist criterion). The oscilloscope voltage directly relates to the magnitude of the displacement.




Figure 1 - Schematic of experimental apparatus and measurement system.

1. Press “AutoSet”.
2. Press yellow 1 button and set the input channel to “AC” on the oscilloscope. A steady line with some small oscillations should appear. This is a real time measurement of the signal from amplifier and is the background signal from the electrical connections corresponding to the noise of the measurement system.
3. Adjust the voltage scale(Vertical) on Channel 1 to be 50 mV/division and adjust the time scale(Horizontal) to be 10 ms/division. This is the scaling required to observe the response of the baseball bat.
4. Set the oscilloscope to trigger in response to an impulse forcing function. This means that the oscilloscope is prepared to record data (trigger) at the moment of the impulse on the bat:
 - Press the Trigger “Menu” button
 - Select the slope menu and choose the icon shown in Fig. 2.
 - Set the source as Channel 1(the trigger is looking for a signal from Channel 1)
 - Set the mode as “Normal”(the trigger is waiting for a single event or impulse to occur), and the coupling as “DC”
 - Move the trigger level knob so that the trigger level is at 20mV – this ensures that the oscilloscope will not trigger until the signal slope falls to this level
 - Using the horizontal position knob, move the trigger arrow, orange “T” at the top of the screen, to the extreme left of the screen
 - Press “Single” button on the top of the scope. The green LED should light up.
5. Above the graph readout on the right hand side there will be some text. Wait for the text to read “Trig?” before proceeding.
6. Keeping safety and those around you in mind, hit the ball with the bat. Do not swing hard as the strain gages will be broken or displaced.
7. Repeat this procedure until a good set of data has been obtained for **both** the single wall and double wall bat.




Figure 2 - Selection for Slope Menu on digital oscilloscope.

Saving Data

1. Press MENU button on the bottom of the scope in the “Save/recall” section.
2. Insert flash drive into scope.
3. Press “Save Waveform” on soft menu on the bottom of the screen.
4. “Source” should be “Ch 1”.

5. Use the multipurpose knob to select the destination. Highlight the “E:\TEK****CH1.CSV” file. The “****” will be replaced by the next sequential number, starting at 0000 when no other files are present.

Fitting Your Data

Your data should look similar to Fig. 3. It should be a nice sinusoid with an exponential decay envelope, just as you would expect for the ringing of a damped harmonic oscillator. If your data is noisy, try using the `smooth()` function in Matlab to filter out the noise. For your lab reports, you will need to quantitatively compare your data with Eq. (3). To do this, we will use the data to calculate λ , ω_d , and ϕ and estimate A .

Consider the peaks labeled y_1 and y_2 . Using Eq. (6), we obtain

$$\frac{y_1}{y_2} = \frac{e^{-\lambda t_1}}{e^{-\lambda t_2}} = e^{\lambda \Delta t} \quad (4)$$

where $\Delta t = t_2 - t_1$. Equation (7) can then be solved for the damping coefficient

$$\lambda = \frac{\ln\left(\frac{y_1}{y_2}\right)}{\Delta t} \quad (5)$$




Figure 3 – An example of “ringing” behavior for a damped harmonic oscillator.

To obtain the ringing frequency ω_d , run the FFT script in Matlab and locate the peak in the plot of relative amplitude vs. frequency. To obtain the phase ϕ in radians, simply find the data point corresponding to the ringing frequency ω_d in the plot of phase vs. frequency. Note that the frequency in both plots is in units of Hz, so ω_d will need to be converted to radians before inserting it in Eq. (3). Also note, the phase ϕ depends on when your scope decided to “trigger” and begin recording data. In this sense, it is somewhat arbitrary and will vary from student to student.

Now that you have ω_d and λ , try to plot Eq. (3) on top of your data. You will need to estimate the amplitude A . In practice, a calibration procedure would be used to convert your data from voltage to units of displacement or strain. For this lab, we will forgo the calibration procedure and estimate the amplitude A instead. To do this, simply adjust A in your Matlab script until both waveforms are approximately the same height.

Lastly, the damping ratio ζ_B of the baseball bat can be obtained using the equation

$$\zeta_B = \frac{1}{\sqrt{1 + \left(\omega_d / \lambda\right)^2}}. \quad (4)$$

Data Analysis and Deliverables

Create plots and other deliverables listed below and put them in a technical memo, as you have done for previous labs.

1. Make a plot of the temperature vs. time for heating and cooling for the 1/16" thermocouples. Adjust the time vectors, so the heating or cooling begins at $t = 0$ for all four data sets. Be sure to include a legend to distinguish the different data sets.
2. Make a plot of the temperature vs. time for heating and cooling for the 1/4" thermocouples. Adjust the time vectors, so the heating or cooling begins at $t = 0$ for all four data sets. Be sure to include a legend to distinguish the different data sets.
3. Examine your data and determine the time constants for heating or cooling of the 1/16" or 1/4" thermocouples. Present the four time constants in a table with a proper caption. Note that the times constants should have units.
4. Make a plot of the **spectral density $|y(f)|$ vs. frequency f for just one of the baseball bats** using the FFT code.
5. Make a plot of the measured **strain gauge output $y(t)$ vs. time t for just one of the baseball bats with a curve fit using Eq. (3)**. For the curve fit, the ringing frequency ω_d and phase ϕ should be obtained from the FFT plots, while the damping coefficient λ should be obtained from Eq. (4) above. For the amplitude A , you will simply have to look at the height of the first oscillation to estimate a value.

Hints and Tips

1. The sine function takes values that have units of radians, so remember to convert ω_d to units of radians per second!
2. For the baseball bat data, remember to delete all of the text at the top of the CSV file, so it only contains data.
3. You may find that your curve fit is *completely* out of phase with the measured signal. This is because the extracted phase ϕ is off by an amount equal to π , which is caused by a mathematical annoyance known as a "branch cut". To correct this, simply add or subtract π from the phase.

Appendix A

Equipment

Part I

- Thermocouple
- Thermocouple Amplifier Box (TAB)
- LabQuest 1 (Aqua-colored) w/ DC power supply
- LabQuest 1 input cable (5V with male banana ends – 24” length)
- BNC connector to female banana receptor
- Large Styrofoam cups (2)
- Hot and Cold water
- Ice cubes
- Mercury thermometer

Part II

- 2 – VGA cable to scope
- 2 – Omega DMD520 strain gage amplifier
- 2 – Tek DPO3012 scope
- 1 – Aluminum bat Single wall
- 1 – Aluminum bat Double wall
- 2 – Tethered softball with stand
- 2 – Bags of tube sand